

AIRPORT DIAGRAM

AL-10 (FAA)

ALBANY INTL (ALB)
ALBANY, NEW YORK

ATIS
 120.45
 ALBANY TOWER
 119.5 257.8
 GND CON
 121.7 348.6
 CLNC DEL 127.5
D

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

42°45.5'N

42°45.0'N

42°44.5'N

42°44.0'N


73°48.5'W

73°48.0'W

73°47.5'W

NE-2, 07 FEB 2013 to 07 MAR 2013

NE-2, 07 FEB 2013 to 07 MAR 2013



AIRPORT DIAGRAM

ALBANY, NEW YORK
ALBANY INTL (ALB)