


# ROSEWOOD THREE DEPARTURE

ATIS 133.675  
 CLNC DEL 120.65  
 GND CON  
 119.45 (EAST)  
 121.8 (WEST)  
 METRO TOWER  
 118.4 317.725 (EAST)  
 135.0 317.725 (WEST)



DETROIT  
 113.4 DXO   
 Chan 81  
 N42°12.79'-W83°22.00'  
 L-28, H-10

R-184

32

SCORR  
 N41°40.31'  
 W83°20.49'

41

CHOOT  
 N41°31.54'  
 W83°20.09'

39

18

R-031

R-028

FLAG CITY  
 108.2 FBC   
 Chan 19

SANDUSKY  
 109.2 SKY   
 Chan 29

R-299

R-284

### SPECIAL INSTRUCTIONS:

Jets use Departure Control Frequency 132.025.  
 Props use Departure Frequency 134.3  
 When using this departure, file the appropriate depicted fix and route.

### TAKE-OFF MINIMUMS:

Rwy's 3L, 3R, 4L, 4R, 9L, 9R, 21L, 21R,  
 22L, 22R, 27L, 27R: Standard.

ROSEWOOD  
 117.5 ROD   
 Chan 122  
 N40°17.27'  
 W84°02.59'  
 L-27, H-10

NOTE: RADAR Required.

NOTE: Chart not to scale.

(NARRATIVE ON FOLLOWING PAGE)

# ROSEWOOD THREE DEPARTURE

EC-1, 07 FEB 2013 to 07 MAR 2013

EC-1, 07 FEB 2013 to 07 MAR 2013