

DALLAS NINE DEPARTURE



DEPARTURE ROUTE DESCRIPTION

PROPS

Expect WYLIE or HUBBARD DEPARTURE

JETS

TAKE-OFF RUNWAYS 13L/R: Climb via heading 130°, expect vectors to appropriate route.

TAKE-OFF RUNWAYS 31L/R: Climb via heading 310° until the LVF or OVW LOCALIZER 5.5 DME, then right turn heading 010° for vector to appropriate route, maintain 5000 feet and expect filed altitude 10 minutes after departure.

TAKE-OFF RUNWAY 18: Climb via assigned heading and altitude (before turning left, climb via heading 180° TO 1300'), expect vector to appropriate route.

TAKE-OFF RUNWAY 36: Climb via heading 360° and assigned altitude, expect vector to appropriate route.

BELCHER TRANSITION (DALL9.EIC): (For aircraft inbound to the JAN, MLU and SHV terminal areas only.) From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to EIC VORTAC.

EL DORADO TRANSITION (DALL9.ELD): (For aircraft inbound to Memphis Terminal area. Aircraft should file and/or expect appropriate STAR.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC.

LITTLE ROCK TRANSITION (DALL9.LIT): From over TTT VOR/DME via TTT R-064 to ORTRO INT, then via LIT R-235 to LIT VORTAC.

MERIDIAN TRANSITION (DALL9.MEI): (For aircraft inbound to the Atlanta Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-097 and MEI R-281 to MEI VORTAC.

QUITMAN TRANSITION (DALL9.UIM): (For aircraft inbound to the Shreveport Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME.

SAWMILL TRANSITION (DALL9.SWB): From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to TEKBE INT, then via SWB R-291 to SWB VOR/DME.

SIDON TRANSITION (DALL9.SQS): From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-077 and SQS R-262 to SQS VORTAC.

SOLDO TRANSITION (DALL9.SOLDO): From over TTT VOR/DME via TTT R-084 to SOLDO INT.

TEXARKANA TRANSITION (DALL9.TXK): From over TTT VOR/DME via TTT R-074 to SHERO INT, then via TXK R-244 to TXK VORTAC.

TAKE-OFF OBSTACLES:

Rwy 13L: Floodlight 965' from DER, 743' right of centerline, 31' AGL/514' MSL. Multiple trees and poles beginning 1166' from DER, 516' to 759' left of centerline, up to 60' AGL/547' MSL.

Rwy 13R: Road, tree, and pole beginning 203' from DER, 480' to 721' right of centerline, up to 38' AGL/514' MSL.

Light standard, sign, rod on stack beginning 691' from DER, 555' to 991' left of centerline, up to 61' AGL/537' MSL.

Rwy 18: Multiple trees and pipe beginning 605' from DER, 93' to 415' left of centerline, up to 41' AGL/523' MSL.

Multiple trees, building, and obstruction light on hangar beginning 300' from DER, 90' to 572' right of centerline, up to 48' AGL/530' MSL.

Rwy 31L: Tree 340' from DER, 408' right of centerline, 10' AGL/ 486' MSL. Tree 253' from DER, 429' left of centerline, 7' AGL/483' MSL.

Rwy 31R: Multiple trees and pole beginning 38' from DER, 329' to 524' left of centerline, up to 13' AGL/490' MSL.

Multiple trees and poles beginning 366' from DER, 553' to 720' right of centerline, 48' AGL/525' MSL.

SC-2, 07 FEB 2013 to 07 MAR 2013

SC-2, 07 FEB 2013 to 07 MAR 2013

DALLAS NINE DEPARTURE