



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 14: Climbing right turn on heading 350° and MEF NDB 272° bearing outbound to GNATS INT. Thence. . . .

TAKEOFF RUNWAY 32: Climb on heading 320° to 1800 then climbing left turn on heading 250° to intercept MEF NDB 272° bearing outbound to GNATS INT. Thence. . . .
. . . .on (transition) or (assigned route). Maintain 11000 or assigned lower altitude.

COPPO TRANSITION (GNATS5.COPPO): From over GNATS INT via OED R-216 to OLECY INT, then via the OED 15 DME Arc to COPPO DME.

DREWS TRANSITION (GNATS5.DREWS): From over GNATS INT via the MEF NDB 272° bearing to MERLI INT, then via the OED 15 DME Arc to DREWS DME.

HANDY TRANSITION (GNATS5.HANDY): From over GNATS INT via the OED R-216 to OLECY INT, then via the OED 15 DME Arc to HANDY DME.

KOLER TRANSITION (GNATS5.KOLER): From over GNATS INT via MEF NDB 272° bearing to MERLI INT, then via RBG R-154 to KOLER INT.

MOURN TRANSITION (GNATS5.MOURN): From over GNATS INT via MEF NDB 272° bearing to MERLI INT, then via the OED 15 DME Arc to intercept OED R-333 to MOURN INT.

TALEM TRANSITION (GNATS5.TALEM): From over GNATS INT via OED R-216 to OLECY INT, then via the OED 15 DME Arc to intercept OED R-157 to TALEM DME.

NW-1, 07 FEB 2013 to 07 MAR 2013

NW-1, 07 FEB 2013 to 07 MAR 2013