



DEPARTURE ROUTE DESCRIPTION

When entering controlled airspace, fly assigned heading and altitude to appropriate route.

ABILENE TRANSITION (WORTH6.ABI): From over TTT VOR/DME via TTT R-250 to PODDE INT, then via MQP R-081 to MQP VORTAC, then via MQP R-253 and ABI R-071 to ABI VORTAC.

BOOMR TRANSITION (WORTH6.BOOMR): (For aircraft inbound LUBBOCK Terminal Area) From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to OWING INT, then via LBB R-085 to BOOMR INT.

CHILDRESS TRANSITION (WORTH6.CDS): From over TTT VOR/DME via TTT R-285 to SCABI INT, then via CDS R-127 to CDS VORTAC.

CORONA TRANSITION (WORTH6.CNX): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC, then via LBB R-272 and CNX R-088 to CNX VORTAC.

GUTHRIE TRANSITION (WORTH6.GTH): From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to GTH VORTAC.

LUBBOCK TRANSITION (WORTH6.LBB): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC.

MILLSAP TRANSITION (WORTH6.MQP): From over TTT VOR/DME via TTT R-250 to PODDE INT, then via MQP R-081 to MQP VORTAC.

PANHANDLE TRANSITION (WORTH6.PNH): From over TTT VOR/DME via TTT R-285 to SCABI INT, then via CDS R-127 to CDS VORTAC, then via CDS R-297 and PNH R-118 to PNH VORTAC.

PODDE TRANSITION (WORTH6.PODDE): (ATC Assigned) From over TTT VOR/DME via TTT R-250 to PODDE INT.

TEXICO TRANSITION (WORTH6.TXO): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC, then via LBB R-305 and TXO R-124 to TXO VORTAC.

TUCUMCARI TRANSITION (WORTH6.TCC): From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to GTH VORTAC, then via GTH R-288 and TCC R-105 to TCC VORTAC.

SC-2, 07 FEB 2013 to 07 MAR 2013

SC-2, 07 FEB 2013 to 07 MAR 2013