



DEPARTURE ROUTE DESCRIPTION

PROPS

Props departing DAL must contact Clearance Delivery for departure instructions.

JETS

TAKE-OFF RUNWAYS 13L/R: Climb via heading 130°, expect vectors to appropriate route.

TAKE-OFF RUNWAY 18: Climb via assigned heading and altitude (before turning left, climb via heading 180° to 1300), expect vector to appropriate route.

TAKE-OFF RUNWAYS 31L/R: Climb via heading 310° until the LVF or OVW localizer 5.5 DME, then turn right heading 010° for vector to appropriate route, maintain 5000 feet and expect filed altitude 10 minutes after departure.

TAKE-OFF RUNWAY 36: Climb via assigned heading and altitude, expect vector to appropriate route.

ARDMORE TRANSITION (TEX1.ADM): From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC.

BLECO TRANSITION (TEX1.BLECO): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to BLECO INT.

EAKER TRANSITION (TEX1.EAKER): (For aircraft inbound to the Tulsa terminal area.) From over FUZ VORTAC via FUZ R-012 to EAKER INT.

GRABE TRANSITION (TEX1.GRABE): (ATC assigned.) From over FUZ VORTAC via FUZ R-012 to GRABE INT.

MCALESTER TRANSITION (TEX1.MLC): (For all aircraft overflying the MLC VORTAC or intercepting J105.) From over FUZ VORTAC via FUZ R-022 to TIKYS INT, then via MLC R-206 to MLC VORTAC.

OKMULGEE TRANSITION (TEX1.OKM): (For all aircraft overflying OKM VOR/DME proceeding via J181 to BDF to destinations in the Chicago terminal area and north.) From over FUZ VORTAC via FUZ R-012 to EAKER INT, then via OKM R-196 to OKM VOR/DME.

ROLLS TRANSITION (TEX1.ROLLS): (For all aircraft proceeding northwestbound via J52.) From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC, then via ADM R-303 to ROLLS INT.

TULSA TRANSITION (TEX1.TUL): (For all aircraft overflying TUL VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via TUL R-201 to TUL VORTAC.

WILL ROGERS TRANSITION (TEX1.IRW): (For all aircraft inbound to the Oklahoma City area or overflying IRW VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via IRW R-145 to IRW VORTAC.

ZEMMA TRANSITION (TEX1.ZEMMA): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT.

TAKE-OFF OBSTACLES:

Rwy 13L: Floodlight 965' from DER, 743' right of centerline, 31' AGL/514' MSL.

Multiple trees and poles beginning 1166' from DER, 516' to 759' left of centerline, up to 60' AGL/547' MSL.

Rwy 13R: Road, tree and pole beginning 203' from DER, 480' to 721' right of centerline, up to 38' AGL/514' MSL. Light standard, sign, rod on stack beginning 691' from DER, 555' to 991' left of centerline, up to 61' AGL/537' MSL.

Rwy 18: Multiple trees and pipe beginning 605' from DER, 93' to 415' left of centerline, up to 41' AGL/523' MSL. Multiple trees, bldg and OL on hangar beginning 300' from DER, 90' to 572' right of centerline, up to 48' AGL/530' MSL.

Rwy 31L: Tree 340' from DER, 408' right of centerline, 10' AGL/486' MSL.

Tree 253' from DER, 429' left of centerline, 7' AGL/483' MSL.

Rwy 31R: Multiple trees and pole beginning 38' from DER, 392' to 524' left of centerline, up to 13' AGL/490' MSL. Multiple trees and poles beginning 366' from DER, 553' to 720' right of centerline 48' AGL/525' MSL.